

Introducing the NEW Udder Comfort Backpack



“Prepares 2-year-olds for robotic milkability.”

Josh Lingen, Lingen Dairy, Balaton, Minn. • 240 through robot, 90 through parlor • SCC 150,000

Pre-fresh Udder Comfort sprayed 1x/day for 6 to 7 days before calving via backpack in headlocks vs. spot application in robot barn after calving

- Heifers came in full of milk, but soft, no edema.
- Fewer udder changes during first 10 days.
- 2 lbs more milk at 14 DIM.
- More efficient robotic milking in first lactation.
- Reduced robot fetch time by more than half.
- Improved speed of attachment.



“Improves first-lactation performance.”

Keith Beer, Beer Cattle Co., Berne, Ind. • Calving 200 heifers/month • Parlor • SCC 150,000

Pre-fresh Udder Comfort sprayed 1x/day for 1 to 2 days before calving and 2x/day 3 to 5 days after calving vs. None

- Gets udders softer, faster, for more milk.
- Overcame edema around teats and suspensory ligament, getting udders ready to accept volumes of milk.
- 3 to 4 lbs more milk at 14 DIM.
- Milk quality improved.



“Promotes clean, quality start to lactation.”

Bob Keefer, Hard Earned Acres, Shippensburg, Pa. • 700 cows • Parlor • SCC 135,000

Pre-fresh Udder Comfort sprayed 1x/day for 5 to 7 days before calving and 2x/day 1 to 2 days after calving vs. 2x/day for 5 to 7 days only after calving

- Zero mastitis in the groups receiving pre-fresh Udder Comfort vs. 5 cases in groups that did not receive pre-fresh Udder Comfort.
- Benefits of softer udders observed visually, less irritation.
- Average 2.5 lbs more milk by 40 DIM



On dairies ranging 360 to 12,000 cows, dairy managers say this about the new backpack:

“Simple, fast, easy way to get the job done.”

“Great for doing pre-fresh in headlocks or stalls.”

“Improves throughput when doing large groups of fresh cows in the parlor.”

“Slick, portable, no air needed.”

“Sprays fast, easy, with cost-effective, uniform coverage fore-udder to rear-udder.”

“On average, 1 gallon did 12 to 14 applications on 40 to 50 fresh/pre-fresh udders.”

“One pass under the udder delivered the spray pattern to the critical area to soften at start of lactation.”

UDDER COMFORT™
Quality Udders Make Quality Milk

Keep the milk in the system

1.888.773.7153 1.613.652.9086
uddercomfort.com



Call to locate a distributor near you.

For external application to the udder only after milking, as an essential component of udder management. Always wash and dry teats thoroughly before milking.